

PRIMA PRO 10L

Oven Toaster Griller

BOROSIL[®]

Performs Beautifully



USER MANUAL

BOTG05

READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE

INTRODUCTION

Congratulation on your purchase of
BOROSIL PRIMA PRO 10L OVEN TOASTER GRILLER (OTG)!

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

Read all instructions before using the product.

- 1) Use only. 230V, 50Hz AC power supply.
- 2) Do not use outdoors or for commercial purposes. (Only for household use).
- 3) Do not operate the appliance if it has malfunctioned or has been damaged in any manner. Never try to repair the appliance by yourself. Contact Borosil Limited for examination and repair.
- 4) Do not touch hot surfaces. Use handles or knobs. Do not move the appliance while it is plugged in.
- 5) Unplug from outlet when not in use and before cleaning. Allow the appliance to thoroughly cool before handling it or before cleaning it.
- 6) Do not let power cord hang over the edge of the table or counter, or touch hot surfaces.
- 7) Never wrap cord tightly around the appliance
- 8) Do not put any stress on the power cord where it connects to the product as the power cord could fray and break.
- 9) Turn the timer knob to "OFF" position to shut off the appliance. After that, switch Off the Mains supply. While unplugging, always hold the plug, never pull the cord.
- 10) To protect against risk of electric shock, do not immerse the cord, plug or cooking unit in water or any other liquid.
- 11) Do not plug or unplug the product into/from an electrical outlet with a wet hand.
- 12) Use the appliance in a well-ventilated area. Keep at least 12 cm of space on all sides of the appliance to allow adequate air circulation.
- 13) Do not place the appliance near to a hot gas / electric burner, or any inflammable product which can harm the appliance.
- 14) Do not leave the appliance unattended while it is in use. The appliance is not intended to be operated by means of an external timer or separate remote-control system.
- 15) Before using, place the appliance on an even, stable surface heat-resistant surface; operate according to the instructions given.
- 16) Do not move the appliance when it is containing hot oil or any hot liquid. make sure the appliance is empty while shifting it.
- 17) Do not cover CRUMB TRAY or any part of the appliance with metal foil. This may cause overheating of the oven which can be dangerous.
- 18) Use extreme caution when removing tray or disposing of hot grease or other hot liquids.
- 19) Do not clean with metal scouring pads. Pieces can break off the pad and touch electrical parts, creating a risk of electric shock.
- 20) Do not insert over-sized foods or metal utensils in the oven as they may create a fire or cause electric shock.

- 21) A fire may occur, if the appliance is covered with flammable materials, including curtains, draperies etc. while in operation. Do not keep any heavy or wet products on the appliance while in operation.
- 22) Extreme caution should be exercised when using containers made of material besides metal or glass.
- 23) Do not place any of the following materials in the appliance : cardboard, plastic, paper, or likewise.
- 24) Do not store any items other than manufacturer's recommended accessories, in this appliance when not in use.
- 25) Always wear protective, insulated oven mitts when inserting or removing items from the heated oven.
- 26) Take care against getting hurt by any sharp edge
- 27) This appliance has a tempered, safety glass door. The glass is stronger than ordinary glass and more resistant to breakage. Avoid scratching the door surface or nicking edges. If the door has a scratch or nick, contact Borosil Customer Care before using the appliance.
- 28) The accessible surfaces are liable to get hot when the appliance is operating.
- 29) Glass door cannot support goods in the fully open position, so do not place any article on it.
- 30) Rear surface of appliances should be placed against a wall.
- 31) **WARNING:** This appliance includes a heating function. Surfaces, other than the functional surfaces may turn hot. Handle the heated appliance with CAUTION. Make use of oven mitts and pot holders while handling the heated surfaces.
- 32) Use this appliance only for its intended use, as described in this manual. Using any accessory attachment not provided with the product may cause hazard or injury. Areas which are not intended for holding/gripping must be given sufficient time to cool.
- 33) This appliance is not intended for usage/cleaning by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless under supervision or given instructions concerning the usage of the appliance by a person responsible for their safety.
- 34) Children should be supervised to ensure that they do not play with the appliance. Keep the appliance and its power cord out of reach to the children.

SAVE THESE INSTRUCTIONS


BEFORE USING YOUR ELECTRIC OVEN

Before using your electric oven for the first time, be sure to:

- 1) Read all instructions and important safeguards included in this manual.
- 2) Make sure oven is unplugged and Timer Knob is in the Off position.
- 3) Remove all racks and pans. Wash the racks and pans in hot sudsy water or in dishwasher.
- 4) Thoroughly dry all accessories and re-assemble in oven. Plug oven into outlet and you are ready to use your new Prima Pro 10L Oven Toaster Griller.
- 5) After re-assembling your oven, we recommend that you run it at MAX temperature for approximately 15 minutes to eliminate any packing oil that may remain after shipping.

Notice: When your Prima Pro 10L Oven Toaster Griller is heated for the first time, it may emit slight smoke or odor. This is normal with many heating appliances. This does not affect the safety of your appliance.

PARTS IDENTIFICATION



PART DESCRIPTION

- | | |
|-----------------------------|-----------------------------|
| 1. Outer body | 7. Power indicator |
| 2. Quartz Heater | 8. Handle |
| 3. Glass door | 9. Grill rack |
| 4. Glass door handle | 10. Food tray/ cooking tray |
| 5. Temperature control knob | 11. Bottom feet |
| 6. Timer knob | 12. In Built Crumb Tray |

- Handle : Allows you to pick up Food tray and Grill rack
- Grill rack : For toasting, baking and general cooking in casserole dishes and standard pans
- Food tray : For use in broiling and roasting meat, poultry, fish & various other food

TECHNICAL SPECIFICATIONS

Product	: OVEN TOASTER GRILLER
Model Name	: PRIMA PRO 10L
Item Code	: BOTG05
Max Capacity	: 10L
Rated Voltage	: 230VAC
Rated Frequency	: 50Hz
Rated Power	: 800W
Household Use Only	

CONTROLS & FUNCTIONS

TEMPERATURE CONTROL KNOB: This knob helps to set the desired temperature for the particular recipe. Temperature range is from Min. to 100°C to 250°C.

TIMER KNOB: The Timer knob is used to set the time as per the requirement of the recipe. To operate the timer, turn the timer clockwise and set it to the required time. Supply to the unit is cut off automatically once it reaches the set time. You can also turn "OFF" the timer knob manually if required. If OTG is required to be on for more than 60 minute, the timer can be bypassed.

POWER INDICATOR: This is illuminated whenever the OTG is turned on.

CLEANING AND MAINTENANCE

This appliance requires little maintenance. It contains no user serviceable parts. In the rare event of any malfunction do not try to repair it yourself. Contact a Borosil Authorized Service Centre.

GENERAL CLEANING & CARE:

- 1) To protect against electrical shock, DO NOT IMMERSE THE OVEN IN WATER OR ANY OTHER LIQUIDS.
- 2) DO NOT USE ABRASIVE CLEANERS OR METAL SCOURING PADS or scrape walls with metal utensils as this may damage the quick-clean interior
 - The oven should be cleaned every time for best performance and long life. Regular cleaning will also reduce the risk of fire hazard
 - After use and before cleaning, switch off the appliance, remove the power plug from the socket. Allow it to cool.
 - Remove the Removable Rack, Tray by pulling them out of the oven. Clean them with damp, soapy cloth. Make sure to only use mild, soapy water.
 - Wash all accessories in hot sudsy water or in a dishwasher.
 - To clean inside of oven, wipe the oven walls, bottom of oven, and glass door with a damp, soapy cloth. Repeat with a dry, clean paper or cloth towel. Clean the exterior with a damp cloth
 - Dry all parts and surfaces thoroughly prior to plugging oven in and using.
 - Store the oven in a clean, dry location such as on a table or counter top.
- **After cleaning the inner chamber of the OTG , reheat the OTG for 1 min at Max temp setting to remove the internal moisture.**

WARRANTY FOR REPAIR AND SALES

This product comes with a warranty of One Year on product from the date of purchase as specified on the Warranty Card. This is against all defective material or workmanship. In the event of a defect, Borosil Limited at its sole choice, will either repair or replace this product or any component of the product found to be defective free of cost through any Borosil Authorized Service Center or at customer place or with dealer from whom it has been purchased during the warranty period.

For any information or problem, contact Borosil Customer Care Toll free no. **1800 224 552** or e-mail us at **myborosil@borosil.com** or contact your local dealer or **Borosil Authorized Service Centre** and provide information about the defect with the model number and serial number of the product.

The warranty is not valid in case:

- 1) Product is not used according to user manual.
- 2) Defects caused by improper or reckless use.
- 3) Repairs done by persons other than Borosil Authorized Service Centre.
- 4) Modifications of any nature made in the product.
- 5) Tampered serial number and incomplete warranty card after purchase.
- 6) Product if used for commercial purpose (i.e. other than domestic use)
- 7) Usage of parts not recommended by Borosil or those made by other manufacturers.
- 8) The model no. on the invoice is different from the product to be repaired
- 9) Borosil is not responsible for accidents arising due to the use of accessories not designed for the utilisation with this product.
- 10) If the defects are caused by fire, flood and the other act of god.
- 11) If the defects are caused by use of incorrect current or voltage or faulty electric power supply.
- 12) All consumables and parts susceptible to normal wear & tear are not covered under warranty.
- 13) This warranty does not cover damage or injury caused by accident, mishandling, misuse or normal wear and tear or for loss of injury, directly or indirectly arising out of use of this product. The decision of the company in this regard shall be final.
- 14) If the product is used with any type of adapter or connector.
- 15) If the product is used in locations with different electrical specifications.

ENVIRONMENT FRIENDLY DISPOSAL



Correct disposal of this product

To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle this product responsibly to promote sustainable reuse of material resources.

WARRANTY CARD

BOROSIL®

**THIS CARD IS VALID ONLY IF IT IS FILLED IN COMPLETELY, SIGNED AND STAMPED
BY THE DEALER ON THE DATE OF PURCHASE**

MODEL CODE: BOTG05

CUSTOMER'S NAME: _____

ADDRESS: _____

PHONE NO. RESIDENCE: _____ OFFICE: _____

DATE OF PURCHASE & BILL NO.: _____

DEALER NAME & SIGN: _____

CUSTOMER'S SIGNATURE: _____

DEALER'S STAMP

BOROSIL®

CORPORATE OFFICE :

BOROSIL LIMITED

1101, G-Block, Parinee Crescenzo, BKC, Bandra (East), Mumbai - 400 051, Maharashtra.
Website: www.borosil.com | Customer Care Toll Free No.: 1800 224 552
Email id: myborosil@borosil.com | Tel: 022 6740 6300 | Fax: 022 6740 6514
CIN NO.: L36100MH2010PLC292722

SALES OFFICE :

MUMBAI:

Kanakia Zillion, B-Wing, Unit No. 306, L.B.S. Marg, Next to Kurla Bus Depot,
Kurla (W), Mumbai - 400 070.
Tel.: 022 6740 6400 | Fax: 022 6740 6444
email: mumbaisales@borosil.com

DELHI:

19/90, P-Block, Connaught Place (Madras Hotel Block), New Delhi - 110 001.
Tel.: 011 2334 3897 / 2374 2136 | Fax: 011 2374 6689
email: delhi@borosil.com

CHENNAI:

New No. 20, (Old No. 9) 1st Floor, Brahdammal Road, Nungambakkam, Chennai - 600 034.
Tel.: 044 2822 6012 / 2822 6013 | Fax: 044 2822 6014
email: borosilmso@ethnet / chennai@borosil.com

KOLKATA:

E-2/3, 2nd Floor, Gillander House, Netaji Subhash Road, Kolkata, West Bengal - 700 001.
Tel.: (033) 2229-9166, 2226-2045
email: calcutta@borosil.com

GURUGRAM:

201, 2nd Floor, CRS Towers, Plot No. 77-B, Village Sarhaul, Iffco Road, Sector-18,
Gurugram, Haryana - 122 015. Tel.: +91 124 6926 318



Now shop India's most trusted brand online at www.myborosil.com

Follow us on Borosil And You

Back Cover - Close Size - 140 x 215 mm